





Mandatory Safety

Caution:

- Please carefully read the instruction manual provided before you use this product, and never use it for purposes other than those listed here.
- Remove all outer packaging before use.
- Use only the power plug contained in the package to avoid damage to the product.
- When unplugging the power adaptor, place your hand on the adaptor body instead of pulling the cord.
- If the unit will not be used for an extended period or needs to be relocated, unplug the power adaptor, dispose of the water, and clean the unit before storage.
- Avoid moving the unit while in use.
- The precautions listed in this user manual are to guarantee the safe and proper use of the Aroma Diffuser, and thereby to protect the user or other persons from any danger and the device from damage. Be sure to follow these instructions.

Warning:

- 
- This device is not intended for use by persons with reduced physical or cognitive capacities without the necessary experience or knowledge, unless they have been trained to use the device correctly by a person responsible for their safety and have understood the risks involved.
- 
- Stop using the product immediately and unplug the device once smoke, smell, unusual sounds or other anomalies occur.
- 
- Do not modify, fix, or dismantle this product, as fire, electric shock, or damage may occur.
- 
- When this product remains unused for a long period of time, the main unit must be unplugged from the electrical socket and water removed. Otherwise electric shock malfunction may occur.
 - This product must be disconnected from the power sources before cleaning and maintenance.
 - Please avoid dripping the essential oil onto the exterior of the device or onto furniture. Is this should accidentally happen, wipe it immediately with a damp cloth and if necessary, use a bit of dish detergent. Essential oils may damage and discolor sensitive surfaces such as plastics or wood. This damage is usually irreversible!
 - This product is not medical equipment. Directly inhaling the aroma mist from the spout is not recommended.
 - If you have any special physical conditions, such as pregnancy, lung failure, cancer, epilepsy, or other illnesses, please consult your doctor before using essential oils. Stop using the product and open the windows for ventilation if you start to feel uncomfortable.
 - Essential oils are highly concentrated and should always be handled with care, including the amount for each use.
 - Do not handle the main unit and outlet with wet hands, or let water or other liquids spill onto them, as this may result in electric shocks.



This product is NOT a toy. Not suitable for use by children. Keep the device, all parts/components, and the power cable out of the reach of children. Children should be properly supervised to ensure that they will not play with this product.

This Aroma Diffuser is to be used under adult supervision only. Please read the detailed instructions and cautionary information before using this for the first time!

Small parts included may be swallowed and cause suffocation. Therefore, these parts should not be stored within reach of children.

Do not spray mist into your eyes or mouth!

To avoid fire, electric shock, injury or damage, do not place the product in the areas listed below:

- **Environments exposed to direct sunlight and temperatures below 10 °C or over 30 °C**
- **Near sources of ignition**
- **Near pressurized containers and combustibles.**

Caution:

1. The unit should be placed on a level solid surface. Do not place on carpets, rugs, wooden/polished furniture, or uneven or unstable surfaces.
2. Use a suitable measuring cup to fill the water tank with water. Never attempt to fill directly under a running tap. Always switch off the device and remove the power cable before filling!
3. Please pay attention to the maximum fill level indicator and do not overfill the tank, to avoid damage to the device.
4. For best results, we recommend that you use 100 % pure essential oils or blends. Artificial fragrances and aromas might soil or damage the unit.
5. Do not use any viscous or strongly coloring essential oils, as the device may sustain damage.
6. Please do not use liquids other than distilled water or tap water at room temperature and 100% pure essential oils or blends.
7. Continuous use of the Aroma Diffuser may damage the product in the long term and shorten its lifetime.
8. Do not cover the device or remove the lid when the Aroma Diffuser is in operation.
9. Device should only be used indoors. Not intended for use in wet rooms.
10. Do not immerse in water or other liquids.
11. If the device falls down, shut it off and unplug it.
12. After use, switch off the device, pour out the water, clean the device, and store it in a dry place.
13. This device is intended for PERSONAL USE ONLY. It must only be used for the purposes described here. Only use the accessories recommended by the manufacturer. This is especially applicable for the power adapter.
14. If any damage occurs to electrical parts, especially if the power cable is faulty, do not operate the device In this case, please contact us or have the device repaired by authorized specialized personnel. Please do not under any circumstances open the device or electrical parts yourself, and do not modify the device.

Safety Advice for the Use of Essential Oils and Fragrance Blends

Please carefully read the instructions provided and the information on the label of your essential oils and fragrance blends. Please do not use viscous or strongly coloring essential oils, as the device may sustain damage. You can obtain more information on this from PRIMAVERA customer service.

Disposal

Disposal If this electric or electronic device is no longer used, all consumers are legally obliged to dispose of it separately from unsorted household waste. Electric devices are therefore marked with the symbol shown below. You can deposit devices at the collection points of the public waste management authorities or at disposal points set up by the manufacturers and retailers within the meaning of the ElektroG (electrical and electronic equipment law). You can find an online directory of collection and disposal points in Germany at www.ear-system.de. These collection points are regulated according to 2012/19/ EU and 2006/66/EC, subject to state and legislation.

We reserve the right to make technical changes to the Aroma Diffuser and any substantive changes to these instructions.



Disclaimer

We accept no liability for damage resulting from incorrect use of this product or caused by the use of essential oils.

Model:	BLB-001
Capacity:	145 ml of water and 3–5 drops of a pure, natural essential oil blend
Operating Modes:	2 and 4 hours of continuous mode operation and 8 hours of intermittent (5 minutes on, 5 minutes off)
Light Modes:	Pastel blue, pastel yellow, pastel purple, continuous color rotation, or light off
Music Mode:	Continuous melody selectable in 3 volume levels
Misting Rate:	Approx. 35 ml per hour
Ultrasonic Frequency:	1.7 MHz
Material:	High quality, BPA free plastic
Power Supply Input:	AC 100 – 240 V, 50/60 Hz
Power supply output:	DC 24 V, 500 mA, 12 W


You can find more information on this product and its application at www.primaverallife.com/aroma-vernebler-funny-friends.html



PRIMAVERA®

Funny Friends

AROMA DIFFUSER



Important Information
About Usage and Cleani

PRIMAVERA LIFE GMBH, Naturparadies 1, 87466 Oy-Mittelberg, Germany, www.primaverallife.com

EN March 2023

Dear Customer,

Thank you for choosing the PRIMAVERA Aroma Diffuser Funny Friends.

To make sure you can enjoy this premium, ultrasonic diffuser for as long as possible, please read these instructions carefully and follow all the safety advice exactly.

We wish you much enjoyment and many fragrant hours with this versatile, easy-to-use fragrance device.

Further information on the product can be found on our website www.primaveralife.com.

Fragrant greetings from the Allgäu,
Your PRIMAVERA Team



Fragrant Fun for the Whole Family

- Interchangeable ears: cat, bear and bunny
- LED light: pastel blue, pastel yellow or pastel purple or in continuous color change mode
- Relaxing melody with sounds of nature can be used to encourage peaceful sleep
- 2 or 4 hours of continuous mode operation or up to 8 hours of interval mode possible
- All functions can be freely combined with each other
- Safety auto switch-off function when tipping over or when the water tank is empty

Instructions for Use in a Child's Room


When using the Aroma Diffuser Funny Friends in a child's room, be sure to limit the scenting time (30 minutes) and to keep the number of aroma oil drops low (3 drops to 145 ml) and to adequately ventilate the room after use.

Tip:


The mist chip has a service life of approx. 3 000 hours of operation. It can be easily replaced. Please get in touch with our PRIMAVERA customer service for this.

Product description



- 1 Top cover
- 2 Main unit
- 3 Internal cover
- 4 Water marker
- 5 Air outlet
- 6 Water tank
- 7 Mist chip
- 8 Mist & Time button
- 9 Light button
- 10 Music button
- 11 Speaker
- 12 Socket
- 13 Power adaptor
- 14 Air inlet
- 15 Mist nozzle
- 16 Cat ear 2 pcs
- 17 Bunny ear 2 pcs
- 18 Bear ear 2 pcs



Interchangeable Ear Features



Instructions



Settings

After the device has plugged into the power outlet, the device will be in the STANDBY mode.

- 1. Mist & Time Button:**
- Press the button once and the unit is turned ON. The default time is 2 hours, indicated by the "2H" green LED light.
 - Press the button a second time and the working time is set to be 4 hours, indicated by the "4H" green LED light.
 - Press the button for the third time and the working time is set to be 8 hours intermittently, indicated by the "8H" green LED light. (5 mins ON and 5 mins OFF)
 - Press the button a fourth time to switch the diffuser OFF.
- 2. Light Button**
- The default rotating lights setting will start automatically while the device is in MIST mode.
 - Press the Light button a first time to switch to "pastel blue".


- Press the Light button a second time to switch to "pastel yellow".
- Press the Light button a third time to switch to "pastel purple".
- Press the Light button a fourth time to switch the light OFF.



- 3. Music Button**
- The music will start automatically while the device is in MIST mode.
 - There are three different sound volume options; keep pressing to adjust the volume (LOW, MEDIUM and HIGH) or OFF the music.
 - MUSIC mode can operate independently as a Music Box function by directly pressing the MUSIC button during the STANDBY mode

- Notes:**
1. A slight difference in mist amount produced by different units is expected.
 2. Factors affecting the mist amount: water, humidity, temperature, and air flow.
 3. There is an auto switch-off function when the diffuser detects the water is empty or when it is tipped over.

Cleaning and Maintenance



- Caution:**
- Please always make sure to clean **after every use** and every change of scent.
 - **Empty the used water daily and remove all deposits and organic films in the container!**
 - Clean the cover and the lower part with a soft cloth.
 - Clean the water tank with a soft, damp cloth.
 - Do not use any corrosive, caustic or abrasive cleaning agents.
 - Use a mild dishwashing solution for heavier soiling.
 - Clean the mist chip very carefully with an alcohol-saturated cotton swap and be careful not to scratch it.
 - Do not immerse the unit in water or other liquids and wait until it has completely dried before operating it again.



72 h